



Potato Bag Instructions

- 1) Warm Tater and your cotton fabrics do not need to be pre-washed. Once complete you will wash together. Measure the inside dimensions of your microwave and adjust the pattern accordingly considering that the finished bag must be at least one full inch away from the walls and door of the microwave. **CAUTION:** If your microwave has a turntable, it is important that your potato bag be allowed to freely rotate or scorching may occur that could lead to fire if left unattended.
- 2) Cut a 22" long x 11" wide piece of Warm Tater cotton and 2 pieces of 100% cotton fabric. One is the lining and the other is decorator fabric.
- 3) Layer the Warm Tater cotton between the two layers of fabric right sides out. Quilt or tack layers together leaving no more than 5" open.
- 4) Serge or sew using a zig zag stitch the 3 layers together on all sides.
- 5) Create finished hems on each of the width ends by folding the fabric to the inside a 1/2" and sewing it down using a straight stitch.
- 6) Fold the fabrics into a 10" square inside out with the hems centered and overlapping 1". Pin and sew all sides with a straight stitch and 1/2" seam allowance.
- 7) Turn right side out. Machine wash cold water and dry in warm dryer before use. Enjoy! Do not microwave Warm Tater bag without food!
 - Potatoes - 2 large = 8 minutes
 - Red Potatoes - 2 large = 8 minutes
 - Sweet Potatoes - 2 medium = 10 minutes
 - Rolls - 3 medium = 20 seconds
 - Tortillas - 1 Package = 30 seconds
 - Corn on the Cob - 2 large = 6 minutesEstimates based on an 1100 watt microwave with turntable. No turntable? Turn your bag over at the midpoint of the suggested cook time to prevent scorching. Wash vegetables. Drying is not necessary as the moisture aids in cooking.

CAUTION: DO NOT LEAVE MICROWAVE UNATTENDED WHEN IN USE!!
WARM TATER IS NOT FIRE RETARDANT OR FLAME PROOF.



(800) 234-9276 www.warmcompany.com