

## Clutch Bag with Upside Down Bobbin Work



### Supply List:

- Sewing Machine
- ¼" Foot or ¼" Right Guide Foot
- 1/3 yard fabric for outside of bag
- 1/3 yard fabric for lining of bag
- 5/8 yard of Shapeflex Interfacing
- Aqua Tear – Tear Away Stabilizer
- Matching sewing thread for sewing the bag together
- Sewing thread to match cords and ribbons
- Open Toe Applique Foot (optional)
- 2mm Silk Ribbon
- Additional bobbin case for bobbin work (optional but highly suggested)
- Trims, ribbons or yarns or specialty bobbin thread for upside down bobbin work
- Rotary cutter and Mat or Scissors, small scissors
- Chalk pencil or water-soluble marker
- Clips or pins
- tweezers
- Iron
- Microtex 80 or 90 Needle

## Prep Work:

1. Cut outside fabric: 9 ½ " x 17" and fuse Shapeflex Interfacing to the back and iron.
2. Cut lining fabric: 9 ½ " x 17" and fuse Shapeflex Interfacing to the back and iron.
3. Fold the fabric rectangle into thirds. Add a piece of Tear Away Stabilizer to the wrong side of the top third of your fabric. This is going to be the top part of your bag. You will mark your horizontal lines on your stabilizer so that you can sew rows of bobbin work – stitching from the wrong side (upside down).



## Sewing Your Bag Together:

4. Once you have finished with your decorating, sew your outer fabric to your lining fabric right sides together. ***Leave an opening on the bottom edge.*** Turn right side out, topstitch the opening closed, and press.
5. Fold into thirds with the stitched section on top to form the flap, and machine-stitch the outer edges of the center and bottom thirds.

