

Serger Trim Catcher
Design by Kim Nipper

You will need:

- *Timtex type product 18 by 9 1/2 inches
- *2-2 1/2 " strips of binding for project
- *1-2 1/2" strip by 12" for pocket
- *2 pieces of fabric for catcher 18 by 9 1/2 inches
- *2 pieces of fabric for pocket and Decor Bond

Cut

11 1/2" across top

7" deep

9 1/2" across bottom

Cut pocket pieces and Decor Bond at 11 1/2" by 7". The top of your pocket should measure the full 11 1/2" and on the bottom measure in and mark one inch. Now on both sides take a ruler and trim sides to go from top corner to bottom side corners. Shaving off the extra. This will now line up nicely for you on the catcher edge

1-Fuse Decor Bond to pocket. Layer with wrong sides facing and add binding to your pocket top.

2-Layer the body of your catcher with Timtex in between. Right sides facing out and position the pocket at the bottom. Pin or clip in place and add binding to complete.