Instructions for making ISOLETTE COVERS

Fabric: two 1-yard pieces of fabric

Batting: one piece of batting, approximately 36" by 40"

Notions: Thread; rotary cutter, mat, and ruler;

straight pins; basting spray



Sewing Instructions:

Iron fabrics and batting (if it's cotton). Square up the cut sides. Remove selvedges from both fabrics. One piece of fabric will likely be a bit smaller than the other, because of slight variations in fabric widths.

Lay the smaller piece right side up on the batting. A light spritz of basting spray will help keep the layers together. Trim exactly around the sides of the fabric, so that the batting is the same size as the fabric.

Place the trimmed fabric/batting right sides together with the larger piece of fabric (the batting will be facing you). Smooth the layers, and pin them together along all four sides.

Using a walking foot on the machine, stitch around the edge of the smaller fabric with a ½" seam, leaving an opening of about 12" on one side for turning.

Trim the excess larger fabric. Trim the corners. Turn the cover right side out, and press the edges carefully. Stitch the opening to close it.

Topstitch all around the cover, about ½" from the edge.

Quilt in a simple grid pattern.