

HOUSE WRAP GOWN

KIT INCLUDES:

- Single piece body
- 1 pair of sleeves per body
- 1 waist tie per body
- 1 neck tie piece per body (this will be cut to length)

GENERAL INFORMATION:

- 3/8 inch seam allowance
- Polyester thread
- Needle size – 80/12 Universal
- Right side of fabric – shiny side
- Stitch width of 3.0

CONSTRUCTION:

STEP 1:

Sew sleeves to armhole cut of the gown body, right sides together, matching red marks

Note: If using pins, pin within 3/8" seam allowance

STEP 2:

Sew shoulder & sleeve top, right sides together, as one seam

Leave thumbhole open, back tack at openings to secure the seam

Laying seam allowances down, tack down tab at thumbhole after sewing sleeve. Be careful in keeping the bottom side of the sleeve out of tab stitching

STEP 3:

Fold waist tie in half lengthwise, shiny sides together

Stitch 1/8" along all 4 sides

Attach waist tie to gown body matching red markings

STEP 4:

Cut neck tie piece in to 14" lengths (yield 3 pieces, use extra for next gown)

Fold pieces in half lengthwise, shiny sides together

Stitch down center of entire length, back tacking at each end

Fold the tab down over the tie and attach the tie to the neck opening using a bar tack

THANK YOU FOR BEING PART OF THIS PROJECT