

Walker Bag Caddy

Fabric

Cut 2 pieces wof and 16 ½ length, one coordinating fabric and one feature fabric

1 piece of batting same size as fabric

2 pieces of sew on Velcro 3 ½"

Instructions:

1. Place fabrics right sides together, place the batting piece on back of one fabric.
2. Stitch around using a ½" seam allowance, leave an opening on one side a little lower than center.
3. Snip corners, turn right side out, iron.
4. Topstitch both short sides only. Quilt top anyway you wish.
5. Attach Velcro on the feature fabric. Fold feature piece in half to find and mark the center. With marking pencil mark both edges top and bottom of center, 5" down from center and 1 ½" in from edge. Separate and place the Velcro starting at the 5", below marked area, sew the loop on one side and the hook on the other side of center.
6. Turn piece with the coordinating fabric face up. Take one end of fabric and bring it up to about 5" from the center and pin sides. Do the same for the other side. Now the feature fabric is showing.
7. Topstitch both sides only, from the very top to the very bottom, reinforcing top edge of pocket.
8. To make pockets, sew a line of stitches in the center of the pocket reinforcing the ends on both sides.

