BERNINA

My BERNINA

Serger Workbook 2



Serging Ahead

For all current BERNINA serger models

Table of Contents



Presser Feet and Accessories	3
Elasticator: Attaching Elastic	4
Gathering Foot: Simple Gathering	5
Gathering Foot: Fabric to Fabric	6
Multi-Purpose Foot: Piping	7
Multi-Purpose Foot: Inserted Piping	8
Multi-Purpose Foot + Gathering	9
Multi-purpose Foot: Beading	10
Blindstitch Foot: Blind Hem	11
Blindstitch Foot: Decorative Tucks	12
Blindstitch Foot: Joining Lace to Lace	13
Cording Foot: Shaped Edges	14
Cording Foot: Wired Edges	15
The remainder of the exercises are for models 1300MDC and 009DCC only:	
3-Needle Cover Stitch	16
2-Needle Cover Stitch	17
Cover Stitch Hem	18
Chain Stitch	19
Decorative Chain Stitch	20
Color-Coded Threading Charts	21



The information in this workbook applies to the current line of BERNINA Sergers. Note: Some exercises apply only to certain models equipped with the feature being highlighted.






Serging Ahead



Presser Feet & Accessories

The following presser feet and accessories are available for all BERNINA serger except the 009DCC. Some attachments are included with the purchase of the serger and others are optional depending on the model. Each presser foot snaps onto the shank of the serger, easy to change without the use of additional tools. The Gathering Attachment, the Guide for the Multi-Purpose Foot, and the Right & Left Seam Guides are attachments used in conjunction with a presser foot.













Elasticator: Attaching Elastic

AMAMAMAMAMAMA

Fabric: Medium weight cotton, 3" x 14" and

12" length of ½" nylon or cotton braid elastic

Needle: 75/11 Stretch or Ballpoint

Thread: 2 cones of serger thread and 2 cones of Woolly Nylon

Presser Foot: Elasticator Stitch: 4-thread overlock

Thread the serger for a 4-thread overlock stitch with the Woolly Nylon in the upper and lower loopers. Adjust settings as directed below.

Attach the Elasticator to the serger.

Locate and raise the roller guide in the front of the presser foot. Turn the handwheel to lower the needles. (This also lowers the feed dog.)

Raise the presser foot and insert the elastic through the slot and under the presser foot until it touches the needles.

Lower the presser foot and serge a few stitches to catch and straighten the elastic along the right edge of the slot. Turn the handwheel to lower the needles.

Lower the roller guide. Using the small screwdriver, loosen the set screw on the front of the elasticator and adjust the guide plate to the width of the elastic; tighten the set screw.

Locate the pressure adjustment set screw (on the top of the roller guide) and turn the screw counterclockwise to completely loosen the pressure on the roller.

Place the fabric under the presser foot and begin serging. Slowly tighten the pressure adjustment set screw to increase the pressure on the roller and stretch the elastic. *Note: Do not over tighten the screw. Excessive pressure on the elastic will bind the fabric.*

Serge the elastic onto the fabric letting the presser foot stretch the elastic for you.

Return all settings to normal.



Suggested Settings

Upper Looper	3-5
Lower Looper	3-5
Left Needle ·····	3-5
Right Needle ·····	3-5
Stitch Length·····	4
Cutting Width	2-3
Differential Feed ·········	N



BERNINA Gathering Foot: Simple Gathering

Fabric: Medium weight cotton, 3" x 12"

Needle: 80/12 Universal

Thread: 4 cones of serger thread Presser Foot: Gathering Foot

Stitch: 4-thread overlock

Thread the serger for a 4-thread overlock stitch. Adjust settings as directed below, starting with a stitch length of 2.5mm and needle tensions of 5.

Attach the Gathering Foot to the serger.

Using a fabric marker, divide fabric into 3 sections along one 12" edge.

Turn the handwheel to lower the needles. (This also lowers the feed dog.) Insert the fabric under the Gathering Foot, up against the needles. The fabric should be on the stitch plate.

Lower the presser foot and serge to the first mark.

Adjust the stitch length to 4mm and serge to the second mark.

Increase the tension on both needles to 7. Serge to the end of the fabric.

Mark the sample as shown.

Return all settings to normal.



Suggested Settings			
Upper Looper ·····	·3-5		
Lower Looper ·····	·3-5		
Left Needle ·····	·5-7		
Right Needle·····	·5-7		
Stitch Length ·····	2.5-4		
Cutting Width	.2		
Differential Feed ······	.2		



BERNINA Gathering Foot: Fabric to Fabric

Fabric: Medium weight cotton, 3" x 14" and

Medium weight cotton, 3" x 8"

Needle: 80/12 Universal

Thread: 4 cones of serger thread Presser Foot: Gathering Foot

Stitch: 4-thread overlock

Thread the serger for a 4-thread overlock stitch. Adjust settings as directed below.

Attach the Gathering Foot to the Serger.

Raise the presser foot and insert the 14" strip of fabric (*right side up*) under the Gathering Foot with the fabric on the stitch plate. Lower presser foot. Sew several stitches until the fabric is under the needles.

Turn the handwheel to lower the needles. (This also lowers the feed dog.) Place the 8" strip of fabric (*right side down*) on top of the flap on the Gathering Foot, touching the needles.

Serge the two strips together; the lower strip will gather as you sew.

Return all settings to normal.



Suggested Settings Upper Looper 3-5 Lower Looper 3-5 Left Needle 3-5 Right Needle 3-5 Stitch Length 4 Cutting Width 2-3 Differential Feed 2



Multi-Purpose Foot: Piping

Fabric: Medium weight cotton bias strip, 2" x 8"

12" length of 3/8" cotton filler cord

Needle: 80/12 Universal

Thread: 4 cones of serger thread

Presser Foot: Multi-Purpose Foot with Guide

Stitch: 4-thread overlock

Set the serger for a 4-thread overlock stitch. Adjust settings as directed below.

Attach the Multi-Purpose Foot and Guide following the directions in the instruction manual for the Multi-Purpose Foot with Guide. *Note: 700D and 800DL need the Attachment Base to accommodate the Guide.*

Insert the filler cord into the guide from front to back.

Raise the Multi-Purpose Foot and insert the filler cord into the guide on the left side of the foot. Feed the filler cord under the foot. Lower the foot and serge a few stitches to stabilize the cord.

Wrap the bias strip around the plastic portion of the guide under the wire that goes over the guide.

Serge slowly, guiding the fabric and the cord simultaneously; continue serging until the cord is covered. It is now ready to be inserted into a seam as it is sewn or serged.



Suggested Settings Upper Looper 3-5 Lower Looper 3-5 Left Needle 3-5 Right Needle 3-5 Stitch Length 3.5 Cutting Width 2-3 Differential Feed N



BERNINA Multi-Purpose Foot: Inserted Piping

Fabric: Medium weight cotton, 3" x 8", 2 pieces

Medium weight cotton bias strip, 2" x 8"

12" length of 3/8" cotton filler cord

Needle: 80/12 Universal

Thread: 4 cones of serger thread

Presser Foot: Multi-Purpose Foot with Guide

Stitch: 4-thread overlock

Set the serger for a 4-thread overlock stitch. Adjust settings as directed below.

Attach the Multi-Purpose Foot and Guide following the directions in the instruction manual for the Multi-Purpose Foot with Guide.

Note: 700D and 800DL need the Attachment Base to accommodate the Guide.


Place one of the 3" x 8" pieces of fabric under the foot, *right side up*.

Wrap the bias strip around the cord and place the wrapped cord in the groove under the foot and on top of the other fabric.

Position the second piece of fabric, *right side down,* on top of the first with the wrapped piping between them.

Serge, making the covered cord and attaching it to the fabric strip in one stitching.

Press the seam allowance to the wrong side of the fabric strip.





Suggested Settings Upper Looper 3-5 Lower Looper 3-5 Left Needle 3-5 Right Needle 3-5 Stitch Length 3 Cutting Width 2 Differential Feed N



Multi-Purpose Foot + Gathering

Fabric: Medium weight cotton, 3" x 18"

Medium weight cotton bias strip, 2" x 8"

12" length of 3/8" cotton filler cord

Needle: 80/12 Universal

Thread: 4 cones of serger thread

Presser Foot: Multi-Purpose Foot + Gathering Attachment

Stitch: 4-thread overlock

Set the serger for a 4-thread overlock stitch. Adjust settings as directed below.

Attach the Multi-Purpose Foot only (no guide), following the directions in the instruction manual for the Multi-Purpose Foot with Guide.


Slip the Gathering Attachment on to the fixing screw and metal post directly behind the fixing screw. *Hint: Place the horseshoe* -shaped slot over the screw, then rotate the attachment to lock over the metal post. Tighten fixing screw. *Note: 700D and* 800DL also need the Attachment Base.

Wrap the bias strip around the cord and place the wrapped cord in the groove under the foot with the raw edges to the right.

Take 2 or 3 stitches into the fabric and lower the needles into the fabric.

Place the 3" x 18" fabric *under* the Gathering Attachment and next to the needles.

Serge, covering the cord, gathering the fabric strip and seaming all layers together.





Suggested Settings			
Upper Looper 3-5			
Lower Looper 3-5			
Left Needle ······ 3-5			
Right Needle ····· 3-5			
Stitch Length····· 3			
Cutting Width ····· 2-3			
Differential Feed ····· 2			



Multi-Purpose Foot: Beading

Fabric: Medium weight cotton, 4" x 8"

10" length of 4mm, plastic, pre-strung beads

Needle: 80/12 Universal

Thread: 3 cones of serger thread
Presser Foot: Multi-Purpose Foot
Stitch: 3-thread narrow flatlock

Set the serger for a 3-thread flatlock stitch using the right needle. Adjust settings as directed below.

Raise the upper knife and lock it in the "up" position. You will not cut fabric with this technique.

Attach the Multi-Purpose Foot only (no guide), following the directions in the instruction leaflet for the Multi-Purpose Foot with Guide.

Lay the pre-strung beads in the channel on the right side of the foot, threading them under the rear guide (see instruction leaflet for the Multi-Purpose Foot with Guide).


Turn the handwheel to encase the first beads inside the thread chain.

Fold the fabric in half to 2" x 8" and place the fabric under the foot with the fold halfway between the needle and the stitch finger or against the right seam guide.

Slowly flatlock the beads to the folded fabric.

Gently pull the fabric flat.

.





Suggested Settings			
Upper Looper 3-5			
Lower Looper 7-9			
Left Needle ······ N/A			
Right Needle ······ 1-2			
Stitch Length······ 1.75			
Cutting Width ····· 2-3			
Differential Feed ······ N			




Blindstitch Foot: Blind Hem

Fabric: Cotton jersey, 6" x 6"

Needle: 80/12 Universal (ballpoint may be used if needed)

Thread: 3 cones of serger thread Presser Foot: Blindstitch Foot Stitch: Narrow 3-thread flatlock



Set the serger for a narrow 3-thread flatlock stitch (right needle); adjust the settings as directed below.

Attach the Blindstitch Foot.

Fold the fabric under for a $1\frac{1}{2}$ " blind hem and then turn the body of the project back so that $\frac{1}{4}$ " - $\frac{1}{2}$ " extends beyond the fold as in a conventional blind hem. Place the fabric under the foot.

Adjust the fabric guide so that the needle just catches the fold in the stitching.

Serge the hem, guiding the fold of the fabric against the guide.

Press the hem.



Suggested Settings Upper Looper 3-5 Lower Looper 7-9 Left Needle N/A Right Needle 1-2 Stitch Length 4 Cutting Width 2-3 Differential Feed N



Blindstitch Foot: Decorative Tucks

Fabric: Medium weight cotton, 6" x 6"

Needle: 80/12 Universal

Thread: 3 cones of serger thread
Presser Foot: Blindstitch Foot
Stitch: 3-thread rolled edge

Set the serger for a 3-thread rolled edge stitch (right needle); adjust the settings as directed below.

Attach the Blindstitch Foot.

Pull the Stitch Selection lever toward you.

Raise the upper knife and lock it in the "up" position. You will not cut fabric with this technique.

Move the fabric guide just to the left of the knife line on the stitch plate.

Mark three lines 1" apart across the fabric.

Fold the fabric *wrong sides together* along one marked line and place the fabric under the presser foot with the fold against the guide.

Serge the tuck; repeat for the two remaining marked lines.

Return the rolled hem lever to the normal serging position.




Suggested Settings Upper Looper 3-5 Lower Looper 7-9 Left Needle N/A Right Needle 3-5 Stitch Length 1.75 Cutting Width 2-3 Differential Feed N



Blindstitch Foot: Joining Lace to Lace

Fabric: Flat edging lace, 2 pieces, 6" each

Needle: 70/10 Sharp or Microtex Thread: 3 cones of serger thread Presser Foot: Blindstitch Foot Stitch: 3-thread rolled edge



Set the serger for a 3-thread rolled edge stitch (right needle); adjust the settings as directed below.

Attach the Blindstitch Foot.

Pull the Stitch Selection lever toward you.

Raise the upper knife and lock it in the "up" position. You will not cut fabric with this technique.

Move the fabric guide just to the left of the knife line on the stitch plate.

Stiffen the lace with spray starch or fabric stiffener.

With right sides together, place the headers of the laces under the presser foot against the guide.

Serge the laces together.

Gently pull the lace flat and press.



Suggested Settings Upper Looper 3-5 Lower Looper 7-9 Left Needle N/A Right Needle 3-5 Stitch Length 1.75 Cutting Width 2-3 Differential Feed N



Cording Foot: Shaped Edge

Fabric: Medium weight fabric, 3" x 18", cut on bias and

Nylon fishing line, 15-20# test, 24"

Needle: 80/12 Universal

Thread: 2 cones of serger thread and 1 cone YLI Woolly Nylon

Presser Foot: Cording Foot Stitch: 3-thread rolled edge

Set the serger for a 3-thread rolled edge (right needle) with Woolly Nylon in the upper looper. Adjust settings as directed below.

Pull the Stitch Selection lever towards you.

Attach the Cording Foot.

Following the directions in the instruction leaflet for the Cording Foot, insert the nylon fishing line through the guides.

Place the fabric under the presser foot and serge along one 18" edge, stretching the fabric edge as you sew.

Return stitch length and thread tension levers to normal.

Return the rolled hem lever to normal sewing position.



Suggested Settings			
Upper Looper 3-5			
Lower Looper 7-9			
Left Needle ······ N/A			
Right Needle ····· 3-5			
Stitch Length······ 1.75			
Cutting Width ····· 1.5			
Differential Feed ······ N			



Cording Foot: Wired Edge

Fabric: Medium weight fabric, 3" x 18" and

28 gauge floral wire, two 24" lengths

Needle: 80/12 Universal

Thread: 2 cones of serger thread and 1 cone YLI Woolly Nylon

Presser Foot: Cording Foot

Set the serger for a 3-thread rolled edge (right needle) with Woolly Nylon in the upper looper. Adjust settings as directed below.

Pull the Stitch Selection lever towards you.

Attach the Cording Foot.

Following the direction in the instruction leaflet for the Cording Foot, insert the wire through the guides.

Place the fabric under the presser foot and serge along one 18" edge, feeding the wire through the foot as you serge.

Use wire cutters to cut the wire. **Do not use the serger knives.**

Repeat for the other 18" edge of the fabric.

Roll hem the short ends of the strip *without* inserting wire into the stitch.

Return stitch length and thread tension levers to normal.

Return the rolled hem lever to normal sewing position.

Secure the thread tails with a seam sealant. When the sealant is dry, cut the thread tails. Use wire cutters to trim the wire, if needed.

Tie the wired fabric into a bow.





Upper Looper 3-5 Lower Looper 7-9 Left Needle N/A Right Needle 3-5 Stitch Length 1.75 Cutting Width 2-3


Differential Feed ······ N

Suggested Settings

3-Needle Cover Stitch

1300MDC only

Fabric: Firm fabric, 3" x 6"
Needle: 80/12 Sharp or JLx2
Thread: 4 cones serger thread
Presser Foot: Cover Stitch Foot
Stitch: 3-needle cover stitch



Set the serger for a 3-needle cover stitch. Adjust settings as directed below. *Note: Model 1300MDC needs to be converted from overlock stitching to cover and chain stitching.*

Attach the Cover Stitch presser foot. Center the fabric under the presser foot. Lift the presser foot and place the fabric completely under the foot.

Turn the handwheel clockwise for the first stitch.

Serge to the end of the fabric.

At the end of the stitching, turn the handwheel counterclockwise until the needles are at their lowest position. Then turn the handwheel clockwise until the needles are at their highest position to release the threads from the looper.

Raise the presser foot and carefully remove the work. Note: At the end of the stitching, turn the handwheel counterclockwise (toward you) until the needle is at its lowest position. Then turn the handwheel clockwise (away from you) until the needle is at its highest position to release the thread from the looper.

Cut the thread using the thread cutter.

Adjust settings as necessary; stitch a second row of cover stitch.




Suggested Settings

	1300MDC
Left Needle	3.2
Center Needle	5
Right Needle	4
Looper	M
Stitch Length	3.5

2-Needle Cover Stitch

Fabric: Firm fabric, 3" x 6"
Needle: 80/12 Sharp or JLx2
Thread: 3 cones serger thread
Presser Foot: Cover Stitch Foot
Stitch: Wide 2-needle cover stitch



Set the serger for a wide 2-needle cover stitch using the left and the right needles. Adjust settings as directed below. *Note: Model 1300MDC needs to be converted from overlock stitching to cover and chain stitching.*

Attach the Cover Stitch presser foot. Center the fabric under the presser foot. Lift the presser foot and place the fabric completely under the foot.

Turn the handwheel clockwise for the first stitch.

Serge to the end of the fabric.

At the end of the stitching, turn the handwheel counterclockwise until the needles are at their lowest position. Then turn the handwheel Clockwise until the needles are at their highest position to release the threads from the looper.

Raise the presser foot and carefully remove the work. Note: At the end of the stitching, turn the handwheel counterclockwise (toward you) until the needle is at its lowest position. Then turn the handwheel clockwise (away from you) until the needle is at its highest position to release the thread from the looper.

Cut the thread using the thread cutter.

Turn the fabric over and stitch another line of cover stitching to show both sides of the stitch on the right side of the fabric.




Suggested Settings				
	009DCC	1300MDC		
Left Needle	3-5	3-5		
Center Needle	N/A	N/A		
Right Needle	3-5	3-5		
Looper	M	M		
Stitch Length	3	3		
Differential Feed ·····	N	N		

Cover Stitch Hem

Fabric: medium weight cotton twill, 4" x 6"

Needle: 80/12 Sharp or JLx2
Thread: 3 cones of serger thread
Presser Foot: Cover Stitch Foot
Stitch: Wide 2-needle cover stitch



Set the serger for a wide 2-needle cover stitch using the left and the right needles. Adjust settings as directed below. *Note: Model 1300MDC needs to be converted from overlock stitching to cover and chain stitching.*

Attach the Cover Stitch presser foot.

Fold up a 2" hem along the 6" edge of the fabric. Glue stick or pin in place.

Using the markings on the stitch plate as a guide, place the fabric under the needles with the fold to the right of the presser foot, with the right side of the fabric up and the hem/wrong side down.

Cover stitch the hem in place.





Suggested Settings			
	009DCC	1300MDC	
Left Needle	3-5	3-5	
Center Needle	N/A	N/A	
Right Needle	3-5	3-5	
Looper	M	M	
Stitch Length	3	3	
Differential Feed ·····	N	N	

Chain Stitch



Fabric: 2 pieces medium weight cotton, each 3" x 6"

Needle: 80/12 Sharp

Thread: 2 cones of serger thread Presser Foot: Chain Stitch Foot

Stitch: Chain



Thread the serger for a chain stitch. Adjust settings as directed below. *Note: Model 1300MDC needs to be converted from overlock stitching to cover and chain stitching.*

Attach the Chain Stitch presser foot. *Note: Model 1300MDC has an exclusive combination presser foot for overlock and chain stitch; model 009DCC has an optional chain stitch foot or the Standard presser foot may be used.*


With right sides together, place the fabric under the needles. Align the raw edges with the 5%" mark on the stitch plate.

Turn the handwheel clockwise for the first stitch.

Serge to the end of the fabric.

Serge 1-2 additional straight or gently curved lines of chain stitching.

Raise the presser foot and carefully remove the work. Cut the thread using the thread cutter.



Suggested Settings				
	009DCC	1300MDC		
Left Needle	N/A	N/A		
Center Needle	N/A	N/A		
Right Needle	3-5	3-5		
Looper	M	M		
Stitch Length	2.5	2.5		
Differential Feed ·····	N	N		

Decorative Chain Stitch

Fabric: Medium weight denim, 6" x 6" and

Tear-away stabilizer, 6" x 8"


Needle: 80/12 Sharp

Thread: 1 cone of serger thread

Decorative thread such as 1 cone Yenmet metallic thread or 1 cone Pearl Crown Rayon thread by YLI

Presser Foot: Chain Stitch Foot

Stitch: Chain stitch



Slightly loosen the tension on the chain stitch looper.


Attach the Chain Stitch presser foot. *Note: Model 1300MDC has an exclusive combination presser foot for overlock and chain stitch; model 009DCC has an optional chain stitch foot or the Standard presser foot may be used.*


Place the stabilizer against the **wrong side** of the denim. Place the denim **right side down** under the presser foot; the stabilizer will be on top.

Chain stitch a curved line across the fabric. Turn the fabric over to see the decorative stitching on the right side.

To increase the amount of decorative thread that shows, adjust the stitch length to 3mm or 4mm. Changing the stitch length as you serge will vary the decorative chain stitch effect. Always use a stitch length of *at least* 2.5mm.

Stitch several more lines of decorative chain stitching across the fabric, using other decorative threads as desired.







Suggested Settings				
	009DCC	1300MDC		
Left Needle	N/A	N/A		
Center Needle	N/A	N/A		
Right Needle	3-5	3-5		
Looper	M	M		
Stitch Length	2.5+	2.5+		
Differential Feed ······	·····N······	N		






















































Chain Stitch













Serging Ahead Class Supplies

Serger Workbook 2

The following fabrics, notions, and accessories are needed to complete the exercises in the My BERNINA Serger Workbook 2: Serging Ahead.

Fabrics Fabrics					
Qty	Fabric Type	Size	Exercises		Examples
3	Medium wt cotton	3" x 14"	Elasticator: Attaching Elastic, pg. 4 Gathering Foot: Simple Gathering, pg. 5 Gathering Foot: Fabric to Fabric, pg. 6		Quilting cotton Medium wt denim
7	Medium wt cotton	4" x 8"	Multi-Purpose Foot: Inserted Piping, pg. 8 Multi-Purpose Foot: Beading, pg. 10 3- Needle Cover Stitch, pg. 16 2-Needle Cover Stitch, pg. 17 Chain Stitch, pg. 19 Decorative Chain Stitch, pg. 20		
1	Medium wt cotton	2" x 8"	Gathering Foot: Fat	oric to Fabric, pg. 6	
3	Medium wt cotton (bias cut)	2" x 8"	Multi-Purpose Foot	Inserted Piping, pg. 8 + Gathering, pg. 9	
3	Medium wt cotton (one cut on bias)	3" x 18"	Multi-Purpose Foot + Gathering, pg. 9 Cording Foot: Shaped Edges, pg. 14 (bias) Cording Foot: Wired Edges, pg. 15		
1	Cotton jersey	6" x 6"	Blindstitch Foot: Blindstitch	Blindstitch Foot: Blind Hem, pg. 11	
1	Medium wt cotton	6" x 6"	Blindstitch Foot: De Cover Stitch Hem, p	corative Tucks, pg. 12 og. 18	Quilting cotton Medium wt denim
			Notions and Acc	cessories	
		otions		Exercises	
	iece of ½" nylon or co			Elasticator: Attaching Elastic, pg. 4	
Three 12" lengths of %" cotton filler cord		Multi-Purpose Foot: Piping, pg. 7 Multi-Purpose Foot: Inserted Piping, pg. 8 Multi-Purpose Foot + Gathering, pg. 9			
	6" lengths of flat edgi			Blindstitch Foot: Lace to Lace, pg. 13	
10" length of 4mm, plastic pre-strung beads Optional: 10" of stranded sequins		Multi-Purpose Foot: Bea			
	f nylon fishing line, 1			Cording Foot: Shaped Edges, pg. 14	
Two 24" lengths of 28 gauge floral wire		Cording Foot: Wired Edges, pg. 15			
Needles and Threads 80/12 Universal / 75/11 Stretch / 70/10 Sharp or Microtex		Exercises For most exercises / pg. 4 / pg. 13			
JLx2 needles		Cover Stitch Exercises, pgs. 16-18			
80/12 Sharp		Chain Stitch Exercises, pgs. 19-20			
4 cones of high quality polyester serger thread		For all exercises <i>Note:</i> some only use 2 or 3.			
2 cones of Woolly Nylon thread		Exercises on pgs. 4, 14, & 15			
1 cone of decorative thread such as Yenmet or Pearl Crown Rayon		Exercises on pgs. 19 & 20			

3/24/11 1 of 1



Serging Ahead Class Supplies

Serger Workbook 2

Accessories	Exercises
Elasticator	Elasticator: Attaching Elastic, pg. 4
Gathering Foot	Gathering Foot: Simple Gathering, pg. 5 Gathering Foot: Fabric to Fabric, pg. 6
Multi-Purpose Foot with Guide Note: 700D and 800DL will also need the Attachment Base.	Multi-Purpose Foot: Piping, pg. 7 Multi-Purpose Foot: Inserted Piping, pg. 8 Multi-Purpose Foot + Gathering, pg. 9 Multi-Purpose Foot: Beading, pg. 10
Gathering Attachment	Multi-Purpose Foot + Gathering, pg. 9
Blindstitch Foot	Blindstitch Foot: Blind Hem, pg. 11 Blindstitch Foot: Decorative Tucks, pg. 12 Blindstitch Foot: Lace to Lace, pg. 13
Cording Foot	Cording Foot: Shaped Edges, pg. 14 Cording Foot: Wired Edges, pg. 15
Cover Stitch Foot	3-Needle Cover Stitch, pg. 16 2-Needle Cover Stitch, pg. 17 Cover Stitch Hem, pg. 18
Chain Stitch Foot (Model 1300MDC has an exclusive combination presser foot for overlock and chain stitch; model 009DCC has an optional chain stitch foot—standard presser foot may be used)	Chain Stitch, pg. 19 Decorative Chain Stitch, pg. 20
Cover Stitch Hem Guide	Cover Stitch Hem, pg. 18

Collect a variety of sewn samples in the classroom to reinforce the serging techniques discussed and shown in class, including techniques serged using accessory presser feet and attachments plus cover and chain stitching.

The following articles are available on Infogate (in the Education folder with the My BERNINA classes) as resource materials, ideas for additional classes, and/or handouts for students to continue the learning process.









3/24/11 1 of 2

MY SERGING EXPERIMENT

BY BARBARA SCHEY

ittle did I think when I went along to a serging workshop to enable myself to be more relaxed with my BERNINA® 2500DCE, I would be writing an article about it for an American magazine! Anne van der Kley was the tutor and her statement (as a retired nurse) that she was "a nurse by profession and a 'sergin' by choice" set the relaxed tone for the workshop. Not that the exercises were relaxed, but the atmosphere was and I will never forget her referring to the upper looper as "that little pointy sticking out thing on top" - it all made sense to me. After thoroughly explaining all the functions of our 16 different machines, we then started on our exercises. And were we to use boring old overlocking thread? Oh no! Anne had us threading and unthreading our machines in a devious plot to convince us that the slowest way to thread the machine was to tie the next thread on to the last.

Eventually we got to the exercise that really interested me. This involved making fabric with the overlocker with the aid of Vilene 541 (those of you in the USA can substitute OESD's Aqua Mesh stabilizer). This product dissolves in cold water but has much more body than other dissolving fabrics and does not require hooping. It also does not dissolve when moist hands touch it. We cut a series of 1" wide strips of the Vilene (length governed by the size of your piece of Vilene). Using embroidery thread in the upper and lower loopers and the left needle, we serged down the right hand edge of a piece of Vilene, then folded under the unserged section of the strip and brought it out to the right and serged down this piece, just catching the edge of the previous line of serging in the second one. This produced a little strip with two overlapping rows of serging. We then laid another strip of Vilene underneath our serged strip, protruding 1/4" to the right. We then serged this strip, just catching the edge of the previous serged strip. The next step was to turn the unserged piece of Vilene under and to the right as before and then serge again. Repeating these steps over and over again resulted in the creation of a very lacy sheet of fabric.

I was fascinated by this exercise and decided it was the answer to a problem I had – how to protect the collar of a miura shibori white jacket and dress I had made. I cut out the paper shape I had in mind to act as a guide. I made the shawl/collar in one piece and cut into it later. I threaded my serger with white rayon embroidery thread in the upper looper,

cream through the lower looper, and a very pale variegated thread on the needle (which had almost no tension on it) to give the piece life. I kept serging and adding strips until I had the desired shape of the collar. I then made a long straight piece, I marked the area that I needed to cut out for the neck, and stitched around it twice with small stitches on my BERNINA® sewing machine. I then cut this piece out and serged around the edge, then serged the center part of one side of the cowl to the neck edge of the shawl/collar. After this I soaked the piece in several changes of water. (I believe the liquid from the first soak is good for stiffening other fabrics.) When the piece dried, I found several places where I had missed serging into the previous row of stitching. A few of these I cheated and stitched with the sewing machine but mostly I hand stitched freshwater pearls around the edges of the spaces, creating a random decorative effect. I also finished off the "ends" of the strips by tying in these little pearls. I used a seam sealant to secure the ends.

This piece was meant to be an accessory to an elegant outfit but ended up taking over. It took me about a day and a half of serging to produce and another day of stitching/tying on pearls but I was very happy with the time spent.

My "normal" work is shibori dyeing fabric (mostly silk georgette) that I stitch into jackets and scarves which I occasionally embellish with freehand embroidery. However, I can see some edges and decorations of serged fabric creeping into this work in the future. I would recommend Anne as a tutor to anyone. I had looked on my 2500DCE as a tool to finish off the edges of my garments, never as a way of creating art pieces, but now I have an entirely different vision of my lovely serger.

BERNINA® Serger Technique Reference Book



Sergers aren't just for making napkins and finishing garment edges. In addition to making "serger lace" fabric as described in Barbara Schey's "My Serging Experiment", they're also great for patchwork, garment construction, home decorating, and more.

To take advantage of all the specialty techniques that can be created using a serger, check out Serger Technique Reference Book. This full-color reference guide contains directions for almost every serger technique imaginable.




Visit your local BERNINA® dealer to "test drive" a serger or two and find out which model best suits your sewing style.



For more information on the "serged fabric" technique Barbara used for serger lace shawl, see Serging Australia: Overlocker Artistry by Anne van der Kley. This inspiring book has something for

everyone - quilting, heirloom, garments, crafts.

Detailed photos and easy-to-follow instructions disprove the notion that "You can't do that with a serger!"



AUSTRALIAN CONTACTS

Barbara Schey

Email: bscheyb@optusnet.com.au

Anne van der Kley

Email: sergingqueen@aol.com