


Adjustable Tape Guide

Overlocker



1



Information

Purpose

- For precise feeding of tapes on the fabric.
- For tapes with a width of 10–60 mm.
- For all overlock, cover and combo stitches.

For Your Safety

Before using this accessory, please read this instruction manual as well as the instruction manual of your machine carefully.

2



Additional Required Materials

- Upper Accessories Holder

Markings and Guides

- A Barrels
- B Clamp
- C Guide on Left-hand Edge of Tape with Locking Screw
- D Guide on Right-hand Edge of Tape
- E Tape Guide Adjustment Rail
- F Knurled Nut

3



Application

Preparing the Adjustable Tape Guide

- ✓ The Upper Accessories Holder is fitted.
- > Remove the knurled nut (F) and connect the individual parts with the knurled nut as shown in the overview.
- > To fit the tape guide, clip the barrels (A) into place over the connecting pins.
- > To remove the tape guide, press down the clamp (B) and pull the tape guide away to the right. (Fig. 2)

4



Feeding the Tape

- > Loosen the locking screw (C) and push it to the left-hand side.
- > Insert the required tape.
- > Push the guide sideways to the left-hand edge of the tape and tighten the locking screw (C). (Fig. 3)
- > Loosen the knurled nut (F).
- > Push the adjustment rail (E) sideways until the right-hand edge of the tape (D) reaches the required position and tighten the knurled nut. (Fig. 4)