

Coverstitch Foot & NEW! Coverstitch Hem Guide

Create professional-looking coverstitched hems – it's easy!

Designed to work with the cover stitch, the Coverstitch Foot (also called the Compensating Foot) has two "floating toes", one on each side of the foot. The "floating toes" help guide the fabric under the foot and prevent sideways motion when stitching hems and seams.

The new Coverstitch Hem Guide is engineered to guide and position the hem so that the stitching is positioned an even distance from the fold, and the raw edge is captured within the looper stitches of the coverstitching. Used in conjunction with the Coverstitch Foot, the new Hem Guide guarantees perfect, professional-looking hems.

TIP: Create decorative hems using heavier threads such as Mettler 30 weight cotton embroidery thread or YLI Jeans Stitch (shown in the photos) – both are available in a wide range of colors, including variegated colorways.

- Set serger for wide or narrow coverstitch as desired, using the Coverstitch foot.
- Fold hem to the wrong side; press in place. Trim hem allowance to desired depth, between 5/8" to 1".
- Attach the Coverstitch Hem Guide to serger using the two attachment screws. Loosen adjusting screw and adjust the depth of the guide to match the folded hem; tighten screw.
- With the right side of the garment facing up, place the hem under the presser foot and guide the hem allowance into the guide so that the fold is against the right side of the guide (1), the hem allowance wraps around the "shelf" of the guide (2), and the raw edge is against the left side of the guide (3). BERNINA®'s exclusive Coverstitch Hem Guide is for use with BERNINA® serger models 2000DCE, 2500DCE, 2500DCE, 1300DC, and Funlock 009DCC.
- Stitch hem, guiding folded edge into the attachment.




Wide 3 thread coverstitch




Narrow 3 thread coverstitch



4 thread coverstitch



Attach hem guide to bed of serger.



Place folded hem into the guide.