

# Serger Crochet



This serger technique can be used in so many applications. Add a little touch of lace on the edges of tea towels and around the bottom of a little girl's dress with this technique using Baby Lock sergers. The results are amazing!

## MATERIALS:

Items to be edged

2 Spools decorative thread; 12wt or 30wt works best

1 Spool all-purpose serger thread to match decorative thread

Clear View foot

## Machine Setup:

- Stitch length: standard 4
- Width: 7.5
- Needle: O1
- Differential feed: N
- Blade locked
- Stitch selector: A

Row 1 – This is the base row for your Serger Crochet edge

- Determine if you prefer to use the raw edge or a folded pressed hem.
- With the right side of the fabric up, place the fabric underneath the foot (about 1/8" to the right of the needle) between the left and right needle marks on the Baby Lock serger foot.
- Serge on the edge of the fabric, making sure that there are loops hanging off of the fabric.
- Continue to serge along the edge of the fabric until you reach the end, flip your project and serge in the opposite direction. Repeat as many times as required.

Row 2

- Starting at the beginning, serge along the loops, catching the loop approximately in the middle. Keeps the loops as flat as possible.

Row 3 +

- Repeat the procedure for Row 2 as many times as preferred, keeping the loops as flat as possible.

### Final Row

- Set the stitch length on 1. Serge along the edge of the loop on the last row. This will create a scalloped lace look on the edge of the previous serging.

### Note:

For a smaller finished edge, add the final row directly to the base row of the serger crochet. For a larger edge, add more middle rows.

Experiment with different thread brands, weights and colors to unleash your creative serging options.