

# Paci-Bib



Finished Size: 8" x 15 ½"

## Supplies Needed


- 1 Fabric Palette® Fat Quarter (18" x 21") - cotton
- 1 Fabric Palette® Cozy Plush (30" x 36")
- ¾" Hook-and-loop tape - 1"
- Coordinating thread
- Removable fabric marker
- Clear tape
- Basic sewing supplies
- Sewing machine
- Iron and pressing surface
- Pressing cloth
- Walking foot (optional)

## Before you begin

Read all instructions before beginning project. Do not prewash fabrics. Before cutting press cotton fabric with a dry iron. Press plush with a damp pressing cloth if needed. **Note:** Pressing directly on plush may damage fabric. Use a ¼" seam allowance and sew fabrics with right sides together (RST) unless otherwise noted. **Note:** When printing, check that page size is set to actual size and compare printout with the template measurements noted in cutting section below.




## Cutting

1. Print Paci-Bib template pieces and tape together along dashed lines. Cut out along printed outside edge. (Template size: 8 ¾" x 16 ½")
2. Cut 2 hook and loop tape pieces to ½" x ¾".
3. Place cotton fabric on top of cozy plush RST. Place the Paci-Bib template on the **wrong** side of cotton fabric; pin well, trace around template and cut out (Dia. A). **Note:** Cozy plush has a nap, which means the fabric will lay flat in one direction. Have the nap lay flat towards the bottom of bib. Remove template.



# Sewing


- Pin well RST and sew  $\frac{1}{4}$ " around the outside edges leaving a 4" opening on one side for turning; clip curves and turn right side out (Dia. B). **Tip:** Using a walking foot will help keep the fabrics from shifting when sewing.
- Use a pressing cloth to press on the cotton side of the Paci-Bib. Topstitch close to edge, sewing the opening closed.
- Pin the hook (rough) side of the hook-and-loop tape to the back side of the left neck tab; sew around edges. Pin loop (soft) side to the front side of the right neck tab. Check that they line up and sew around edges (Dia. C).
- To make the loop for the pacifier, refer to the pattern to pin the hook (rough) side of the hook-and-loop tape to the Paci-Bib back and the loop (soft) side on the Paci-Bib back as shown on Template C. Check that they line up then sew around edges (Dia. D)



# Finished Care Instructions

Machine wash cold, gentle cycle. Tumble dry low or hang to dry.






Paci-Bib Template B

Leave 4" open for turning

Line up pieces at dashed lines for full-size template



Line up pieces at dashed lines for full-size template