creative signature" Embroidery Programs

PFAFF® creative™ Line Comparison Chart















		TM	
creative	ICO	n	1


	creative icon [™] 2	creative performance 950	o creative expression™ 750	creative [™] 3.0	creative [™] ambition [™] 640	creative expect [™] 350
		Embro	idery Features			
Design Projection	•					
Hoop Scanning	•		•			
Design Library On-Screen*	•	•	•			•
<i>creative</i> ™ Embellishment Attachment Capability^	•	•				
Embroidery Unit Size	360 x 350	360 x 350	360 x 350	260 x 200	240 x 150	170 x 100
Create Shape	•	•	•			
Create Appliqué	•	•	•			
Select Thread Colors by Brand Numbers	•	•	•			
Embroidery Design Resize	•	•	•		•**	
Color Block Sort	•	•	•			
Color Block Merge	•	•	•		•**	
Change Stitch-Out Order	•	•				
Grouping	•	•	•		•**	•
Embroidery Stitch Editor	•	•	•			
Change Embroidery Colors	•	•	•		•**	•
Multi-Select Designs	•	•	•	Select One or All	•**	Multi-Select
Embroidery Design Scale	•	•	•	•	•	•
Rotate Designs	1º Increments	1º Increments	1º Increments	1º Increments	•	•
Mirror Designs	•	•	•	•	•	•
Monochrome	•	•	•	•	•	
Basting in the Hoop	Two Options	Two Options	Two Options	•	•	

^{*} Subscription required after 30 days.

[^] Optional accessory.

^{**} Embroidery computer software is included in the creative ambition 640 sewing and embroidery machine.




















		DEAD			1	7	PIAN
		creative icon™ 2	creative performance [™] 950	creative expression™ 750	creative [™] 3.0	creative [™] ambition [™] 640	creative expect [™] 350
	Radiant Stitches	•	•	•			
	Floating Stitches	•	•	•			
	Lace Edge Stitches	•	•	•			
	Ribbon Stitches	Triple, Double, and Single	Triple, Double, and Single	Triple, Double, and Single			
	Maxi Stitches	•	•	•			
	Stacking Stitches	•	•	•			
	Electronic Knee-Lift	•	•	•			
	Sew with Embroidery Unit on	•	•	•			
	Automatic Feed Dog Drop	•	•	•			Embroidery Only
	Stitch Creator™ Feature	•	•	•	•		
SC	Patchwork Program	•	•	•	•		
rar	Single Stitch Program	•	•	•	•		
Sewing Programs	Tapering on all 9 mm Decorative Stitches	•	•	•	•		
Ϋ́	Mirror Image	•	•	•	•	•	
Se	Stitch Positioning	•	•	•	•		•
	Automatic Presser Foot Lift	•	•	•	•		
	Adjustable Presser Foot Pressure	•	•	•	•	•	
	Start/Stop - Sew without the foot control	•	•	•	•	•	•
	Needle Up/Down	•	•	•	•	•	•
-	Free-Motion Options	4	4	4	3	1	1
	Extra Presser Foot Lift	•	•	•	•	•	•
	Sequencing	•	•	•	•	•	•
	Program Sequencing Commands	•	•	•	•		
	Sensormatic One Step Buttonhole	•	•	•	•	One Step Buttonhole	One Step Buttonhole

creative signature Sewing Programs

Twin-Needle Program



















	 TM 	_
creative	ıcon	٠,
CICGIIVC	10011	_

	creative icon [™] 2	creative performance™ 950	creative expression™ 750	creative™ 3.0	creative™ ambition™ 640	creative expect™ 350
On-Screen Help	Getting Started, Video Tutorials, Sewing Projects, Needle and Accessory Guides	Getting Started, Video Tutorials, Sewing Projects, Needle and Accessory Guides	Getting Started, Video Tutorials, Sewing Projects, Needle and Accessory Guides			
Quick Help System	•	•	•	•	Info Button	
Telescopic Thread Guide	•	•				
LED Lights	Shadow Eliminating	Shadow Eliminating	•	•	•	•
Accessory Feet Included	12	12	11	8	8	7
Rubberized Accessory Tray	•	•				
Stylus and Built-In Stylus Holder	Capacitive Touch No Stylus Needed	Capacitive Touch No Stylus Needed	Capacitive Touch No Stylus Needed	•		Stylus Included
Top and Bobbin Thread Sensor	•	•	•	•	Top Thread Sensor	•
Bobbin Winding from the Needle	•	•	•	•	•	
Clock, Timer, Stopwatch, Alarm Capabilities	•	•				
Personal Menu	mySewnet Cloud Storage	mySewnet Cloud Storage	CREATIVATE Vault Storage	3 x 10	1 x1	mySewnet Cloud Storage
Speed Ranges	Variable Speed Slider	Variable Speed Slider	Variable Speed Slider	•	Speed Slider	Speed Slider
Updateable	•	•	•	•	•	•
USB Connectivity	2 Port	2 Port	1 Port	1 Port	1 Port	1 Port