

GO! Fractured Tumbler Oven Mitt

Finished Size: 13" x 8"



Designed by Jennifer Strauser of Dizzy Quilter

Fabrics provided by Andover Fabrics

Dies Needed:

GO! Fractured Tumbler-3" Finished (55627)

GO! Oven Mitt (55563)

GO! Strip Cutter-2-1/2" (2" Finished) (55017 or 55014)

Fabric Requirements:

Fabric Color	Total Yardage
4 colors	Fat quarter each
Lining fabric	Fat quarter
Hanging loop	Scrap
Insu bright	1/2 yard or 20" x 14"
Batting	1/2 yard or 20" x 14"

Cutting Directions:

Fabric Color	Die	Number of Shapes to Cut
4 colors	GO! Fractured Tumbler-3" Finished (55627)	Cut 3—4-3/4" x 18" rectangles. Fan fold and place on B blades to cut pieces of each color. If not, fan folding, make sure half of your pieces are facing up, and half are facing down, as we are making 2 sets of blocks, one with a mirror image.
Lining	GO! Oven Mitt (55563)	Cut 2 – 10" x 14" rectangles. Place on die with one piece print side up, and the other print side down. Cut out 2 oven mitt shapes.
Hanging loop	GO! Strip Cutter-2-1/2" (2" Finished) (55017 or 55014)	Cut 1—8" x 3" strip. Place on die and cut 1 strip.
Insu bright	GO! Oven Mitt (55563)	Cut 2 – 10" x 14" rectangles. Place on die and cut out 2 oven mitt shapes. Or you can cut them later in the process for perfect alignment.
Batting	GO! Oven Mitt (55563)	Cut 2 – 10" x 14" rectangles. Place on die and cut out 2 oven mitt shapes. Or you can cut them later in the process for perfect alignment.

Pieced blocks

Press all seams open and use 1/4" seams, unless otherwise indicated.

1. Separate your pieces into two sets – one oriented in each direction. Pay attention to how you orient the pieces. It is easy to get the shapes confused and stitch together incorrectly.
2. Pin pieces together.



3. Stitch, then press open.
4. Combine two units to make a complete block, pressing center seam open.



5. Repeat to make 14 of each block.
6. Lay out your blocks to make the following shapes.

7. Assemble blocks into rows, press seams open.
8. Assemble rows together, pressing seams open.



Hanging Loop

1. Fold the long sides of the loop into the middle and press.
2. Fold in half, hiding the raw edges. Press.
3. Top stitch, 1/8" away from the edge, along both sides.
4. Fold in half and set aside.

Assemble the Oven Mitt

1. Layer Insu bright, batting, and pieced tops. Pin in 4-5 spots to keep your layers aligned.
2. Quilt as desired.
3. Place your quilted panels on your die, one at a time. Make sure you align one with the piecing up, and the other with the piecing down, so that you get front and back pieces.
4. Use clips to align the oven mitt sides, right sides together, and stitch around the outside. When you get into the area between the thumb and fingers, shorten your seam allowance until you are nearly at the point of the clip. This will make it easy to turn your oven mitt and get a crisp inner point.
5. Take your two lining fabrics and stitch them together, right sides together, following the same stitch line at the thumb joint.
6. Take your lining and turn it right side out and slip it into the inside outer panel of the oven mitt. The two pretty sides should be touching.
7. Slide the folded hanging loop in between the two fabric layers, aligning the raw edges at the shorter seam. Pin.
8. Pin the raw edges of your lining and oven mitt in place, being careful to line up the seam lines. Leave a gap of 3-4 inches unsewn, for turning.
9. Stitch around the opening of the oven mitt, backstitching at your start and stop point.
10. Pull the lining and the oven mitt through the hole you have left open. It will take a little bit of patience. Just keep working at it and pulling a little at a time through until you have the oven mitt right side out. Tuck the lining inside.
11. Tuck the edges of the opening in, pinning to make sure the lining is to the inside of your oven mitt. Top stitch around the edge of your oven mitt to secure it.